



Seepage (ft/day) = abs Qin-Qout(ft³/sec) x 84600 / Length(ft) x Wetted Perimeter(ft), created with Pynomo, JWIII